

Date: Maintenance operation" list Check No. "Maintenance operation" list Check CHECK CERECT MOVEMENTS – BRISE SOLEIL BLADES OK/NO 1 MOVE THE BLADES COMMANDING A FULL RUN FROM COMPLETELY CLOSED TO COMPLETELY OPEN AND VICE VERSA
No. "Maintenance operation" list Check CHECK CORRECT MOVEMENTS - BRISE SOLEIL BLADES OK/NO 1 MOVE THE BLADES COMMANDING A FULL RUN FROM COMPLETELY CLOSED TO COMPLETELY OPEN AND VICE VERSA
CHECK CMOVE THE BLADES SOLEIL BLADES OK/NO 1 MOVE THE BLADES COMMANDING A FULL RUN FROM COMPLETELY CLOSED TO COMPLETELY OPEN AND VICE VERSA
CHECK CMOVE THE BLADES SOLEIL BLADES OK/NO 1 MOVE THE BLADES COMMANDING A FULL RUN FROM COMPLETELY CLOSED TO COMPLETELY OPEN AND VICE VERSA
1 MOVE THE BLADES COMMANDING A FULL RUN FROM COMPLETELY CLOSED TO COMPLETELY OPEN
AND VICE VERSA
2 CHECK THERE ARE NO FOREIGN BODIES BLOCKING MOVEMENT, REMOVE ANY THAT ARE FOUND
3 CHECK THE CORRECT POSITION OF THE DRAW BAR AT THE OPENING AND CLOSING ENDSTOPS
4 LUBRICATE MOVING PARTS WITH TEFLON SPRAY (DRAW BAR PLASTIC SADDLES – GUIDE PORTION
CAMS COUPLED WITH WHEELS)
5 USE THE REMOTE CONTROL TO COMMAND THE LIMIT LEARNING PROCEDURE
CHECK THE STATE AND FOR ANY OBSTRUCTIONS IN PERIMETER GUTTERS AND BRISE SOLEIL BLADE GUTTERS. OK/NO
CHECK THE STATE AND FOR ANY OBSTRUCTIONS IN COLLARS AND CORNER DRAIN PIPES AT THE TOP AND
BOTTOM OF THE COLUMNS.
6 INSPECT GUTTERS, DRAINPIPES, COLUMNS, DRAINS
7 REMOVE ANYTHING THAT OBSTRUCTS THE WATER DOWNFLOW, REMOVING ANY FOREIGN PARTS
(E.G. LEAVES, PINE NEEDLES, ETC.)
8 CHECK THE SEALS ARE IN GOOD CONDITION: (ESPECIALLY CORNER GUTTERS AND GUTTER PLUGS
HOLDING THE PERIMETER LED LIGHTS)
CHECK THE SUPPORTING STRUCTURE OK/NO
9 CHECK THE GOOD STATE AND TIGHTNESS OF THE NUTS AND BOLTS
10 CHECK THE FLOOR AND WALL ATTACHMENTS ARE IN PERFECT CONDITION
11 CHECK THE CONDITION AROUND THE ATTACHMENTS (ESPECIALLY THAT THERE ARE NO CRACKS AND
THAT THE SCREWS ARE TIGHT), IF THERE ARE PROBLEMS INFORM THE CUSTOMER
CHECK THE SENSORS, AUTOMATISMS AND ELECTRIC PARTS OK/NO 12 CHECK THE REMOTE CONTROLS WORK AND THE BATTERIES ARE CHARGED □
14 CHECK THE LIGHTING SYSTEM WORKS CORRECTLY (IF INSTALLED) □ 15 CHECK THE AUDIO SYSTEM WORKS CORRECTLY (IF INSTALLED) □
16 CHECK THE ELECTRIC CONNECTIONS ARE UNDAMAGED
17 CHECK THEM ACCORDING TO THE TYPE OF SIDE WINDOWS THAT ARE INSTALLED
18 RECORD THE WORK IN THE MANUALS OR TECHNICAL MAINTENANCE CHARTS FOR EACH PRODUCT